



**TANGO**  
Device  
Server

# **CellCouette User's Guide**

## **CellCouette Class**

**Revision: release\_1\_1\_7 - Author: vince\_soleil**  
**Implemented in C++ - CVS repository: tango-ds**

### **Introduction:**

this device is used to control a specific sample environnement called Cell Couette. This equipement is consisted of 3 parts: - the motor controller - the torque controller - temperature controller the multiplexage is ensured by a multipoint link RS-485. but sometime theses controllers can be in concurrency. To improve the communication, THE STATE COMMAND MUST BE POLLED BY THE USER (under JIVE application). The other attributes which read on the hardware are polled by default. Moreover, to ensure the communication , the elapsed time between 2 RS232 requests is at least 500 ms The device communicates with controllers by using the Serial Device (RS232 communication) the communication parameters of the associated proxy device server called Serial are: Baudrate = 19200; Charlength = 8; Newline = none; Serialline = COMx; stopbits = 0; Timeout = 2000 3 modes are available: CONTINUOUS: the rotor rotates continuously OSCILLATION: the rotor oscilates RAMP: the rotor rotates continuously by speed steady period

## Class Inheritance:

- Tango::Device\_4Impl
  - CellCouette

## Properties:

Device Properties		
Property name	Property type	Description
<b>SerialProxyName</b>	Tango::DEV_STRING	name of the serial device proxy
<b>TorqueCalibrationCoefficient</b>	Tango::DEV_DOUBLE	TorqueCalibrationCoefficient

Device Properties Default Values:

Property Name	Default Values
SerialProxyName	No default value
TorqueCalibrationCoefficient	1

**There is no Class properties.**

## States:

States	
Names	Descriptions
<b>MOVING</b>	the rotor is moving
<b>STANDBY</b>	the rotor is stopped
<b>FAULT</b>	serial communication problem

## Attributes:

Scalar Attributes			
Attribute name	Data Type	R/W Type	Expert
<b>mode:</b> mode = 0 means CONTINUOUS mode = 1 means OSCILLATION	DEV_USHORT	WRITE	No
<b>cellRadius:</b> is used to calculate: - the distortion in oscillation mode - the stress torque - the shear rate in continuous mode	DEV_DOUBLE	WRITE	No
<b>cellGap:</b> used to calculate the distortion in oscillation mode	DEV_DOUBLE	WRITE	No
<b>positionUnity:</b> used to select the position unity (discret values) 0: STEP unity 1: DEGREE unity the conversion law is: $10000 \text{ step} \Leftrightarrow 360^\circ \cdot \frac{1}{2}$	DEV_USHORT	WRITE	No
<b>position:</b> current rotor position, unity is based on position unity	DEV_DOUBLE	READ_WRITE	No
<b>speedUnity:</b> used to select the speed unity (discret values) 0: STEP_PER_SECOND 1: HERTZ 2: ROTATION_PER_MINUTE 3: RADIAN_PER_SECOND 4: SHEAR_RATE	DEV_USHORT	WRITE	No
<b>speedMax:</b> prevent too high speed value. unity is based on the speed unity attribute	DEV_DOUBLE	READ_WRITE	No
<b>isPositiveRotation:</b> to select either positive or negative rotation	DEV_BOOLEAN	READ_WRITE	No
<b>speed:</b> write part: speed preset if resolution = 1 $\Rightarrow$ 0.01Hz < range speed < 2 Hz) if resolution = 64 $\Rightarrow$ 2 Hz < range speed < 128 Hz) this value can't exceed speedMax attribute value read part: estimated value by calculation ( $\Delta \text{position} / \Delta t$ )	DEV_DOUBLE	READ_WRITE	No
<b>halfAngularAmplitude:</b> defines the half angular amplitude in oscillation mode as: $\theta_{\min} = -\theta$ and $\theta_{\max} = +\theta$ the unity is based on position unity attribute	DEV_LONG	READ_WRITE	No
<b>frequency:</b> used in WT (motor time ramp) and WH(high hard motor speed) calculations	DEV_DOUBLE	WRITE	No
<b>deformation:</b> $\text{deformation} = \theta * (R + dR) / dR$	DEV_DOUBLE	READ	No
<b>timeRamp:</b> - in continuous mode: - write part : WT preset - read part = write part - in oscillation mode: - read part : calculated value as $WT = \text{period} \times (0.5 - 1/\pi) \times 1000$ (in ms) - write part : no available to apply the preset value call the SetMotorParam Command	DEV_DOUBLE	READ_WRITE	No
<b>speedMaxRamp:</b> - in continuous mode: - write part : WH preset - read part = write part - in oscillation mode: - read part : calculated value as $WH = (2 * \pi * \theta) / T$ - write part : no available	DEV_LONG	READ_WRITE	No
<b>weightOffset:</b> capteur offset in gramms	DEV_DOUBLE	WRITE	No
<b>weight:</b> F sensor measurement	DEV_DOUBLE	READ	No
<b>cellHeight:</b> cell Height	DEV_DOUBLE	WRITE	No
<b>torque:</b> torque measurement in micro Nm	DEV_DOUBLE	READ	No
<b>stress:</b> $\text{stress} = M / (2 * \pi * R^2 * H)$	DEV_DOUBLE	READ	No
<b>temperature:</b> sample temperature	DEV_DOUBLE	READ	No

<b>motorResolution:</b> set motor resolution: possible values are: 1, 2, 4, 8, 16, 32, 64. the resolution has an effect on the rotor speed	DEV_USHORT	WRITE	No
<b>viscosity:</b> $\text{viscosity} = (1000 * M / 2 * \pi * \text{speed}(\text{Rad} * \text{sec}^{-1})) * (1 / (H * R^2 (R + \Delta R) / \Delta R + 4R^4 / (8.465 * 16 - H)))$	DEV_DOUBLE	READ	No

## Commands:

More Details on commands....

Device Commands for Operator Level		
Command name	Argument In	Argument Out
<b>Init</b>	DEV_VOID	DEV_VOID
<b>State</b>	DEV_VOID	DEV_STATE
<b>Status</b>	DEV_VOID	CONST_DEV_STRING
<b>Start</b>	DEV_VOID	DEV_VOID
<b>Stop</b>	DEV_VOID	DEV_VOID
<b>PowerOFF</b>	DEV_VOID	DEV_VOID
<b>Reset</b>	DEV_VOID	DEV_VOID
<b>SetMotorParam</b>	DEV_VOID	DEV_VOID
<b>GetMotorParam</b>	DEV_VOID	DEV_STRING
<b>GetMotorState</b>	DEV_VOID	DEV_STRING

Device Commands for Expert Level Only		
Command name	Argument In	Argument Out
<b>SendCommand</b>	DEV_STRING	DEV_STRING

## 1 - Init

- Description:** This commands re-initialise a device keeping the same network connection.  
 After an Init command executed on a device, it is not necessary for client to re-connect to the device.  
 This command first calls the device *delete\_device()* method and then execute its *init\_device()* method.  
 For C++ device server, all the memory allocated in the *nit\_device()* method must be freed in the *delete\_device()* method.  
 The language device desctructor automatically calls the *delete\_device()* method.
- Argin:**

**DEV\_VOID** : none.

- **Argout:**

**DEV\_VOID** : none.

- **Command allowed for:**

- Tango::MOVING
- Tango::STANDBY
- Tango::FAULT

## 2 - State

- **Description:** This command gets the device state (stored in its *device\_state* data member) and returns it to the caller.

- **Argin:**

**DEV\_VOID** : none.

- **Argout:**

**DEV\_STATE** : State Code

- **Command allowed for:**

- Tango::MOVING
- Tango::STANDBY
- Tango::FAULT

## 3 - Status

- **Description:** This command gets the device status (stored in its *device\_status* data member) and returns it to the caller.

- **Argin:**

**DEV\_VOID** : none.

- **Argout:**

**CONST\_DEV\_STRING** : Status description

- **Command allowed for:**

- Tango::MOVING
- Tango::STANDBY
- Tango::FAULT

## 4 - Start

- **Description:** start the motor motion according to the operating mode selected (either CONTINUOUS or OSCILLATIONS) - CONTINUOUS MODE: this is the write part of speed attribute which define the rotor speed once you push on start comand - OSCILLATIONS MODE: execute a sequence memorized in the controller (already programmed in the firmware)
- **Argin:**  
**DEV\_VOID** : nothing
- **Argout:**  
**DEV\_VOID** : nothing
- **Command allowed for:**
  - Tango::MOVING
  - Tango::STANDBY
  - Tango::FAULT

## 5 - Stop

- **Description:** stop the motor motion
- **Argin:**  
**DEV\_VOID** : nothing
- **Argout:**  
**DEV\_VOID** : nothing
- **Command allowed for:**
  - Tango::MOVING
  - Tango::STANDBY
  - Tango::FAULT

## 6 - PowerOFF

- **Description:** cut the motor power
- **Argin:**  
**DEV\_VOID** : nothing
- **Argout:**  
**DEV\_VOID** : nothing
- **Command allowed for:**
  - Tango::MOVING
  - Tango::STANDBY

- Tango::FAULT

## 7 - Reset

- **Description:** the rotor returns to the default state (note that the encoder position is set to 0)
- **Argin:**  
**DEV\_VOID** : nothing
- **Argout:**  
**DEV\_VOID** : nothing
- **Command allowed for:**
  - Tango::MOVING
  - Tango::STANDBY
  - Tango::FAULT

## 8 - SendCommand (for expert only)

- **Description:** send a specific command to the specified controller. You must specify the controller address in the string to send. address list: 15: motor controller 03: temperature controller 02: torque controller ex: "15QX" where: 15 : the address of the motor controller (2 bytes) QX: is the command (N bytes)
- **Argin:**  
**DEV\_STRING** : command to send
- **Argout:**  
**DEV\_STRING** : controller response
- **Command allowed for:**
  - Tango::MOVING
  - Tango::STANDBY
  - Tango::FAULT

## 9 - SetMotorParam

- **Description:** Once you have written new values of speedMax, motorResolution, timeRamp attributes you must call setMotorParam(), thus new motor parameters are sent to the motorController
- **Argin:**  
**DEV\_VOID** : nothing
- **Argout:**  
**DEV\_VOID** : nothing

- **Command allowed for:**

- Tango::MOVING
- Tango::STANDBY
- Tango::FAULT

## 10 - GetMotorParam

- **Description:** get motor parameters

- **Argin:**

**DEV\_VOID** : nothing

- **Argout:**

**DEV\_STRING** : motor parameters

- **Command allowed for:**

- Tango::MOVING
- Tango::STANDBY
- Tango::FAULT

## 11 - GetMotorState

- **Description:** return a message which inform you on the motor state

- **Argin:**

**DEV\_VOID** : nothing

- **Argout:**

**DEV\_STRING** : motor state

- **Command allowed for:**

- Tango::MOVING
- Tango::STANDBY
- Tango::FAULT

TANGO is an open source project hosted by :

**SOURCEFORCE.NET®**

Core and Tools : CVS repository on tango-cs project  
Device Servers : CVS repository on tango-ds project