



**TANGO**  
Device  
Server

# **SY900S\_Group User's Guide**

## **SY900S\_Group Class**

Revision: release\_2\_0\_5 - Author: vince\_soleil  
Implemented in C++ - CVS repository: tango-ds

### **Introduction:**

this device controls one group of channels. Every channels of one group reply by the same way

### **Class Inheritance:**

- Tango::Device\_4Impl
  - SY900S\_Group

### **Properties:**

Device Properties		
Property name	Property type	Description
<b>GroupNumber</b>	Tango::DEV_LONG	one group is consisted of severals channels. this property assigns the group number.
<b>SY900SgenericProxyServer</b>	Tango::DEV_STRING	name of the generic device server proxy

Device Properties Default Values:

Property Name	Default Values
GroupNumber	No default value
SY900SgenericProxyServer	No default value

**There is no Class properties.**

## States:

States	
Names	Descriptions
<b>FAULT</b>	memory allocation problem
<b>STANDBY</b>	wait for a command
<b>RUNNING</b>	SY900S busy

## Attributes:

Scalar Attributes			
Attribute name	Data Type	R/W Type	Expert
<b>voltagesAppliedOnAllChannels:</b> sets the output voltage over all channels of the same group	DEV_DOUBLE	WRITE	No
<b>deltaVoltagesOverAllChannels:</b> This is a differential voltage. The Voltage attribute equal = current voltage + differential voltage sets the output voltage of all channels from a same group N	DEV_DOUBLE	WRITE	No
<b>group:</b> get the current device group number	DEV_LONG	READ	No

## Commands:

More Details on commands....

Device Commands for Operator Level		
Command name	Argument In	Argument Out
<b>Init</b>	DEV_VOID	DEV_VOID
<b>State</b>	DEV_VOID	DEV_STATE
<b>Status</b>	DEV_VOID	CONST_DEV_STRING
<b>On</b>	DEV_VOID	DEV_VOID
<b>Off</b>	DEV_VOID	DEV_VOID
<b>ResetError</b>	DEV_VOID	DEV_VOID
<b>SetChannelsTargetVoltage</b>	DEV_VOID	DEV_VOID
<b>GetLastError</b>	DEV_VOID	DEV_STRING

### 1 - Init

- **Description:** This commands re-initialise a device keeping the same network connection.  
After an Init command executed on a device, it is not necessary for client to re-connect to the device.  
This command first calls the device *delete\_device()* method and then execute its *init\_device()* method.  
For C++ device server, all the memory allocated in the *nit\_device()* method must be freed in the *delete\_device()* method.  
The language device desctructor automatically calls the *delete\_device()* method.
- **Argin:**  
**DEV\_VOID** : none.
- **Argout:**  
**DEV\_VOID** : none.
- **Command allowed for:**
  - Tango::FAULT
  - Tango::STANDBY
  - Tango::RUNNING

## 2 - State

- **Description:** This command gets the device state (stored in its *device\_state* data member) and returns it to the caller.
- **Argin:**  
**DEV\_VOID** : none.
- **Argout:**  
**DEV\_STATE** : State Code
- **Command allowed for:**
  - Tango::FAULT
  - Tango::STANDBY
  - Tango::RUNNING

## 3 - Status

- **Description:** This command gets the device status (stored in its *device\_status* data member) and returns it to the caller.
- **Argin:**  
**DEV\_VOID** : none.
- **Argout:**  
**CONST\_DEV\_STRING** : Status description
- **Command allowed for:**
  - Tango::FAULT
  - Tango::STANDBY
  - Tango::RUNNING

## 4 - On

- **Description:** switches on all the channels of a same group
- **Argin:**  
**DEV\_VOID** :
- **Argout:**  
**DEV\_VOID** :
- **Command allowed for:**
  - Tango::STANDBY
  - Tango::RUNNING

## 5 - Off

- **Description:** switches off all the channels of a same group. Vouts = 0 V after pushing init. Moreover, after switching ON, Output voltages stay at 0 V.
- **Argin:**  
**DEV\_VOID :**
- **Argout:**  
**DEV\_VOID :**
- **Command allowed for:**
  - Tango::FAULT
  - Tango::STANDBY
  - Tango::RUNNING

## 6 - ResetError

- **Description:** erase all error message
- **Argin:**  
**DEV\_VOID :**
- **Argout:**  
**DEV\_VOID :**
- **Command allowed for:**
  - Tango::FAULT
  - Tango::STANDBY
  - Tango::RUNNING

## 7 - SetChannelsTargetVoltage

- **Description:** This command sets all channels to the voltage defined by each target voltage attributes in the SY900S\_channel device.
- **Argin:**  
**DEV\_VOID :**
- **Argout:**  
**DEV\_VOID :**
- **Command allowed for:**
  - Tango::FAULT
  - Tango::STANDBY
  - Tango::RUNNING

## 8 - GetLastError

- **Description:** this function get the las error message which has occured
- **Argin:**  
**DEV\_VOID :**
- **Argout:**  
**DEV\_STRING :** error message
- **Command allowed for:**
  - Tango::FAULT
  - Tango::STANDBY
  - Tango::RUNNING

TANGO is an open source project hosted by :  
**SOURCEFORGE.NET®**

Core and Tools : CVS repository on tango-cs project  
Device Servers : CVS repository on tango-ds project