FestoCompAirDistributor Tango Cpp Class

Contents :

- Description
- Properties
- Commands
  - State
  - Status
- Attributes
  - Valve1
  - Valve2
  - Valve3
  - Valve4
  - Valve5
  - Valve6
  - Valve7
  - Valve8
  - Valve9
  - Valve10
- States

FestoCompAirDistributor Class Identification :

Contact	: at mail.desy.de - tnunez
Class Family	: Instrumentation
Platform	: Unix Like
Bus	: Ethernet
Manufacturer	: Fento
Manufacturer ref.	: CompressedAirDistributor

FestoCompAirDistributor Class Inheritance :

- Tango::DeviceImpl
  - FestoCompAirDistributor

FestoCompAirDistributor Class Description :

Class for writting/reading on the valves of the Compressed Air Distributor from Fento.

FestoCompAirDistributor Properties :

There is no class properties

Device Properties			
Name	**Description**	**Type**	**Default Value**
AdsServer	Name of the Ads Tango device	String	none

FestoCompAirDistributor Class Commands				
Name	**Input type**	**Output type**	**Level**	**Description**
State	DEV_VOID	DEV_STATE	OPERATOR	This command gets the device state (stored in its device_state data member) and returns it to the caller.
Status	DEV_VOID	CONST_DEV_STRING	OPERATOR	This command gets the device status (stored in its device_status data member) and returns it to the caller.

Command State :

This command gets the device state (stored in its device_state data member) and returns it to the caller.

State Definition		
Input Argument	Tango::DEV_VOID	none

Output Argument	Tango::DEV_STATE	Device state
DisplayLevel	OPERATOR	..
Inherited	true	..
Abstract	true	..
Polling Period	Not polled	..
Command allowed for	All states	..

Command Status :

This command gets the device status (stored in its device_status data member) and returns it to the caller.

Status Definition		
Input Argument	Tango::DEV_VOID	none
Output Argument	Tango::CONST_DEV_STRING	Device status
DisplayLevel	OPERATOR	..
Inherited	true	..
Abstract	true	..
Polling Period	Not polled	..
Command allowed for	All states	..

FestoCompAirDistributor Class Attributes							
Name	**Inherited**	**Abstract**	**Attr. type**	**R/W type**	**Data type**	**Level**	**Description**
Valve1	false	false	Scalar	READ_WRITE	Tango::DEV_LONG	OPERATOR	0 -> open, 1->close
Valve2	false	false	Scalar	READ_WRITE	Tango::DEV_LONG	OPERATOR	0 -> open, 1->close

Valve3	false	false	Scalar	READ_WRITE	Tango::DEV_LONG	OPERATOR	0 -> open, 1->close
Valve4	false	false	Scalar	READ_WRITE	Tango::DEV_LONG	OPERATOR	0 -> open, 1->close
Valve5	false	false	Scalar	READ_WRITE	Tango::DEV_LONG	OPERATOR	0 -> open, 1->close
Valve6	false	false	Scalar	READ_WRITE	Tango::DEV_LONG	OPERATOR	0 -> open, 1->close
Valve7	false	false	Scalar	READ_WRITE	Tango::DEV_LONG	OPERATOR	0 -> open, 1->close
Valve8	false	false	Scalar	READ_WRITE	Tango::DEV_LONG	OPERATOR	0 -> open, 1->close
Valve9	false	false	Scalar	READ_WRITE	Tango::DEV_LONG	OPERATOR	0 -> open, 1->close
Valve10	false	false	Scalar	READ_WRITE	Tango::DEV_LONG	OPERATOR	0 -> open, 1->close

---

There is no dynamic attribute defined.

Attribute Valve1 :

0 -> open, 1->close

Attribute Definition	
Attribute Type	Scalar
R/W Type	READ_WRITE
Data Type	Tango::DEV_LONG
Display Level	OPERATOR
Inherited	false
Abstract	false

Attribute Properties
label
unit
standard unit
display unit
format
max_value
min_value
max_alarm

Attribute Event Criteria	
Periodic	Not set
Relative Change	Not set
Absolute Change	Not set
Archive Periodic	Not set

Polling Period	Not polled
Memorized	Not set
Read allowed for	All states
Write allowed for	All states

min_alarm
max_warning
min_warning
delta_time
delta_val

Archive Relative Change	Not set
Archive Absolute Change	Not set
Push Change event by user code	false
Push Archive event by user code	false
Push DataReady event by user code	false

Attribute Valve2 :

0 -> open, 1->close

Attribute Definition	
Attribute Type	Scalar
R/W Type	READ_WRITE
Data Type	Tango::DEV_LONG
Display Level	OPERATOR
Inherited	false
Abstract	false
Polling Period	Not polled
Memorized	Not set
Read allowed for	All states
Write allowed for	All states

Attribute Properties
label
unit
standard unit
display unit
format
max_value
min_value
max_alarm
min_alarm
max_warning
min_warning
delta_time
delta_val

Attribute Event Criteria	
Periodic	Not set
Relative Change	Not set
Absolute Change	Not set
Archive Periodic	Not set
Archive Relative Change	Not set
Archive Absolute Change	Not set
Push Change event by user code	false

Push Archive event by user code	false
Push DataReady event by user code	false

Attribute Valve3 :

0 -> open, 1->close

Attribute Definition	
Attribute Type	Scalar
R/W Type	READ_WRITE
Data Type	Tango::DEV_LONG
Display Level	OPERATOR
Inherited	false
Abstract	false
Polling Period	Not polled
Memorized	Not set
Read allowed for	All states
Write allowed for	All states

Attribute Properties	
label	
unit	
standard unit	
display unit	
format	
max_value	
min_value	
max_alarm	
min_alarm	
max_warning	
min_warning	
delta_time	
delta_val	

Attribute Event Criteria	
Periodic	Not set
Relative Change	Not set
Absolute Change	Not set
Archive Periodic	Not set
Archive Relative Change	Not set
Archive Absolute Change	Not set
Push Change event by user code	false
Push Archive event by user code	false
Push DataReady event by user code	false

Attribute Valve4 :

0 -> open, 1->close

Attribute Definition	
Attribute Type	Scalar
R/W Type	READ_WRITE
Data Type	Tango::DEV_LONG
Display Level	OPERATOR
Inherited	false
Abstract	false
Polling Period	Not polled
Memorized	Not set
Read allowed for	All states
Write allowed for	All states

Attribute Properties	
label	
unit	
standard unit	
display unit	
format	
max_value	
min_value	
max_alarm	
min_alarm	
max_warning	
min_warning	
delta_time	
delta_val	

Attribute Event Criteria	
Periodic	Not set
Relative Change	Not set
Absolute Change	Not set
Archive Periodic	Not set
Archive Relative Change	Not set
Archive Absolute Change	Not set
Push Change event by user code	false
Push Archive event by user code	false
Push DataReady event by user code	false

Attribute Valve5 :

0 -> open, 1->close

Attribute Definition	
Attribute Type	Scalar
R/W Type	READ_WRITE
Data Type	Tango::DEV_LONG
Display Level	OPERATOR
Inherited	false
Abstract	false
Polling Period	Not polled
Memorized	Not set
Read allowed for	All states
Write allowed for	All states

Attribute Properties
label
unit
standard unit
display unit
format
max_value
min_value
max_alarm
min_alarm
max_warning
min_warning
delta_time
delta_val

Attribute Event Criteria	
Periodic	Not set
Relative Change	Not set
Absolute Change	Not set
Archive Periodic	Not set
Archive Relative Change	Not set
Archive Absolute Change	Not set
Push Change event by user code	false
Push Archive event by user code	false
Push DataReady event by user code	false

Attribute Valve6 :

0 -> open, 1->close

Attribute Definition	
Attribute Type	Scalar
R/W Type	READ_WRITE
Data Type	Tango::DEV_LONG
Display	OPERATOR

Attribute Properties
label
unit
standard unit
display unit
format

Attribute Event Criteria	
Periodic	Not set
Relative Change	Not set
	Not

Level	
Inherited	false
Abstract	false
Polling Period	Not polled
Memorized	Not set
Read allowed for	All states
Write allowed for	All states

max_value
min_value
max_alarm
min_alarm
max_warning
min_warning
delta_time
delta_val

Absolute Change	set
Archive Periodic	Not set
Archive Relative Change	Not set
Archive Absolute Change	Not set
Push Change event by user code	false
Push Archive event by user code	false
Push DataReady event by user code	false

Attribute Valve7 :

0 -> open, 1->close

Attribute Definition	
Attribute Type	Scalar
R/W Type	READ_WRITE
Data Type	Tango::DEV_LONG
Display Level	OPERATOR
Inherited	false
Abstract	false
Polling Period	Not polled
Memorized	Not set

Attribute Properties
label
unit
standard unit
display unit
format
max_value
min_value
max_alarm
min_alarm
max_warning
min_warning

Attribute Event Criteria	
Periodic	Not set
Relative Change	Not set
Absolute Change	Not set
Archive Periodic	Not set
Archive Relative Change	Not set
Archive Absolute Change	Not set

Read allowed for	All states
Write allowed for	All states

delta_time
delta_val

Push Change event by user code	false
Push Archive event by user code	false
Push DataReady event by user code	false

Attribute Valve8 :

0 -> open, 1->close

Attribute Definition	
Attribute Type	Scalar
R/W Type	READ_WRITE
Data Type	Tango::DEV_LONG
Display Level	OPERATOR
Inherited	false
Abstract	false
Polling Period	Not polled
Memorized	Not set
Read allowed for	All states
Write allowed for	All states

Attribute Properties
label
unit
standard unit
display unit
format
max_value
min_value
max_alarm
min_alarm
max_warning
min_warning
delta_time
delta_val

Attribute Event Criteria	
Periodic	Not set
Relative Change	Not set
Absolute Change	Not set
Archive Periodic	Not set
Archive Relative Change	Not set
Archive Absolute Change	Not set
Push Change event by user code	false
Push Archive event by user code	false
Push DataReady event by user code	false

Attribute Valve9 :

0 -> open, 1->close

Attribute Definition	
Attribute Type	Scalar
R/W Type	READ_WRITE
Data Type	Tango::DEV_LONG
Display Level	OPERATOR
Inherited	false
Abstract	false
Polling Period	Not polled
Memorized	Not set
Read allowed for	All states
Write allowed for	All states

Attribute Properties
label
unit
standard unit
display unit
format
max_value
min_value
max_alarm
min_alarm
max_warning
min_warning
delta_time
delta_val

Attribute Event Criteria	
Periodic	Not set
Relative Change	Not set
Absolute Change	Not set
Archive Periodic	Not set
Archive Relative Change	Not set
Archive Absolute Change	Not set
Push Change event by user code	false
Push Archive event by user code	false
Push DataReady event by user code	false

Attribute Valve10 :

0 -> open, 1->close

Attribute Definition	
Attribute Type	Scalar
R/W Type	READ_WRITE
Data Type	Tango::DEV_LONG
Display Level	OPERATOR
Inherited	false
Abstract	false
Polling Period	Not polled
Memorized	Not set
Read allowed for	All states
Write allowed for	All states

Attribute Properties
label
unit
standard unit
display unit
format
max_value
min_value
max_alarm
min_alarm
max_warning
min_warning
delta_time
delta_val

Attribute Event Criteria	
Periodic	Not set
Relative Change	Not set
Absolute Change	Not set
Archive Periodic	Not set
Archive Relative Change	Not set
Archive Absolute Change	Not set
Push Change event by user code	false
Push Archive event by user code	false
Push DataReady event by user code	false

FestoCompAirDistributor Class States	
Name	**Description**
ON	
FAULT	